

Hanging mount for V7 ultra low-profile vandal domes

DWC-V7HMW



WHAT'S IN THE BOX

V7 Camera Mounting Screws (M3.0x8mm)		2	Quick Setup Guide		1
DA Camera Mounting Screws (M3.0x10mm)		2			

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



INSTALLATION

- 1 Secure the hanging mount to the pole (NTP 3/4 thread).
- 2 Before attaching the camera to the hanging mount, remove the dome from the camera base.
- 3 Pass wires through and make all necessary connections.
- 4 Use the camera mounting screws (included with bracket) to secure the camera to the mount cap.
- 5 Adjust the camera lens modules' position and complete the installation by placing the dome cover on the camera. See the camera's QSG for camera setup information.

NOTE: Do not touch the lenses when handling the camera modules.

