

Hanging mount for vandal dome, turret and fisheye cameras

DWC-VFHMW



WHAT'S IN THE BOX

<p>Camera Mounting Screws</p>	<p>M3.0x 10mm M3.0x 20mm with Rubber Gasket M3.0x 23mm M3.0x 35mm</p>	<p>5 sets</p>	<p>Quick Setup Guide</p>		<p>1</p>
-------------------------------	--	---------------	--------------------------	--	----------

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



INSTALLATION

- 1 Secure the hanging mount to the pole (NTP 3/4 thread).
- 2 Before attaching the camera to the hanging mount, remove the dome from the camera base.
- 3 Pass wires through and make all necessary connections.
- 4 Use the camera mounting screws (included with bracket) to secure the camera to the mount cap. See the table below for the length of the screws and compatible cameras.

Screw size	Compatible camera
10mm screws 	DWC-XSDA models
20mm screws 	DWC-MV8 and DWC-MPV8 models DWC-MVC and DWC-MPVC models DWC-PVF and DWC-PPVF models DWC-MF and DWC-MPF models
23mm screws 	DWC-VA models DWC-MVA models DWC-MPVA models
35mm screws 	DWC-MVD and DWC-MPVD models

- 6 Adjust the camera lens module's position and secure the dome cover to the camera. See the camera's QSG for camera setup information.

*** NOTE: How to tell what MF, V8 or PVF hardware you have:**

If the camera's mounting holes are located on the outer edge of the camera's base, use the 20mm screws WITHOUT the washers.

If the camera's mounting holes are located on the inner edge of the camera's base, use the 20mm screws with the rubber washers included.

